

John Martin Picnic Shelter BBQ Instructions

To Start BBQ:

- 1. Please Ensure Roll Up Gate is All the Way Up** (BBQ and Hood Fan will not start if the gate is not all the way up and making contact in the top right corner).
- 2. Push the Red Button** to reset the roll up gate contact.
- 3. Push the Green Button** to turn on the Hood Fan (If the Fan does not start, please check that the gate is all the way up and making contact at the top right corner).
- 4. Unlock the gas valve**, then use the enclosed wrench to turn on the gas. Turn one ¼ turn counterclockwise (the valve wrench should be in line with the pipe).
- 5. There are 2 separate BBQ's.** At the lower right of the BBQ, turn on the igniter switches to use either the left and/or right sides (the clicking igniters will shut off once the pilot is warm and will stay on. It will do this automatically after a couple of minutes). **Leave the switches on.**
- 6. Turn up the valves as needed.** Please wait for heat as these BBQ's can be slow to start sometimes.



To Turn Off BBQ:

- 1. Turn off the BBQ igniter switches.**
- 2. Turn off and lock the gas valve.** Put the wrench back in the cabinet.
- 3. Push the red button** to turn off the hood fan.
- 4. Close and lock the roll-up gate.**
- 5. Lock up the cabinet.**

John Martin Stove Burner BBQ Instructions

To **Start** Burners:

1. **Please Ensure Roll Up Gate is All the Way Up** (BBQ and Hood Fan will not start if the gate is not all the way up and making contact in the top right corner).
2. Push the Red Button to reset the Roll Up Gate contact.
3. Push the Green Button to turn on the Hood Fan (If the Fan does not start, please check that the gate is all the way up and making contact at the top right corner).
4. Unlock gas valve, then use the enclosed wrench to turn the gas on. One ¼ turn down counterclockwise. (The valve wrench should be in line with the pipe).
5. Open front cabinet doors of the Burner Unit. Set selected Burner Valve to the star. While pushing in the selected valve, press the red igniter switch at the bottom right corner of the cabinet. Once lit let out the knob and turn to the desired heat.
6. Each Burner has its own separate pilot light and will need to be lit separately.
7. The pilot lights can be slow to start sometimes and may take a few tries to get going.



To **Turn Off** Burners:

1. Turn off all the Burner Valves used.
2. Turn off and lock gas valve. Put wrench back in the cabinet.
3. Push the red button to turn off the Hood Fan.
4. Close and lock up Roll Up Gate.
5. Lock up cabinet.