





# AN EXAMPLE OF A TYPICAL, QUALITY ELEVATION DRAWING



\*\*\*NOTE\*\*\*  
IF HIGH EFFICIENCY FURNACE IS NOT USED - FRAME CHIMNEY AS PER MAIN FLOOR PLAN

\*\*\*NOTE\*\*\*  
ENSURE THAT BASE OF COLUMN DOES NOT OVERHANG CONC. STEP

\*\*\*NOTE\*\*\*  
END CONCRETE WALL 6\" FROM REAR WALL TO ACCOMMODATE FULL WOOD FRAME CONSTRUCTION

\*\*\*NOTE\*\*\*  
LOCATION OF DROPPED FOOTINGS TO BE LOCATED ON SITE BY EXCAVATOR/CRIBBER/GENERAL CONTRACTOR. EXACT LOCATION MAY VARY FROM BLUEPRINTS DUE TO NEIGHBORING GRADES/NATURAL GRADES AND/OR ON SITE CONDITIONS

\*\*\*NOTE\*\*\*  
END CONCRETE WALL 6\" FROM REAR WALL TO ACCOMMODATE FULL WOOD FRAME CONSTRUCTION

\*\*\*NOTE\*\*\*  
LOCATION OF DROPPED FOOTINGS TO BE LOCATED ON SITE BY EXCAVATOR/CRIBBER/GENERAL CONTRACTOR. EXACT LOCATION MAY VARY FROM BLUEPRINTS DUE TO NEIGHBORING GRADES/NATURAL GRADES AND/OR ON SITE CONDITIONS